

Rețele de Calculatoare

Aplicații uzuale: DHCP, FTP, HTTP

Sumar al laboratorului

1

DHCP

Caracteristici generale
Mesaje transmise
Configurare DHCP

2

FTP

Ce transferăm
Cum transferăm

3


HTTP

Cadrele HTTP
Cum se încarcă o pagină web



DHCP

Caracteristici generale




Atenție: Acești parametri sunt dați în regim de închiriere

Atenție: Folosește UDP-ul pentru transport

DHCP


Caracteristici generale




DHCP

Mesajele transmise

Prima închiriere



Reînnoirea



DHCP

Antetul protocolului

8	16	24	32
OP code (1)	Hardware Type (1)	Hw address length (1)	Hops (1)
Transaction Identifier (4)			
Seconds (2)		Flags (2)	
Client Ip Address (4)			
Your Ip Address (4)			
Server Ip Address (4)			
Gateway Ip Address (4)			
Client Hardware Address (16)			
Server Name (64)			
Boot Filename (128)			
DHCP Options (variabil)			

Transaction Identifier –
Câmp unic pentru
fiecare schimb de
mesaje cu un host

Boot Filename –
Fișier ce poate folosi la
pornirea unor dispozitive

DHCP options –
Aici vedem tipul de
mesaj transmis

DHCP

Alocare adresă IP - Windows

General

You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the appropriate IP settings.

☐ Obtain an IP address automatically

☒ Use the following IP address:

IP address: 192 . 168 . 50 . 10

Subnet mask: 255 . 255 . 255 . 0

Default gateway: 192 . 168 . 50 . 1

☐ Obtain DNS server address automatically

☒ Use the following DNS server addresses:

Preferred DNS server: . . .

Alternate DNS server: . . .

☐ Validate settings upon exit

Advanced...

OK Cancel

Internet Protocol Version 4 (TCP/IPv4) Properties

General **Alternate Configuration**

You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the appropriate IP settings.

☒ Obtain an IP address automatically

☐ Use the following IP address:

IP address: . . .

Subnet mask: . . .

Default gateway: . . .

☒ Obtain DNS server address automatically

☐ Use the following DNS server addresses:

Preferred DNS server: . . .

Alternate DNS server: . . .

☐ Validate settings upon exit

Advanced...

OK Cancel


DHCP

Alocare adresă IP - Linux

```
network:
  version: 2
  renderer: networkd
  ethernets:
    ens33:
      dhcp4: no
      dhcp6: no
      addresses: [192.168.1.100/24]
      gateway4: 192.168.1.1
      nameservers:
        addresses: [8.8.8.8,8.8.4.4]
root@server1:/#
```




Prin editarea fișierului de networking – de ex cu vi, nano, etc.

Prin interfața grafică



DHCP

Alocare statică – bazată pe MAC

▼ Devices				
List	Tree	RouterOS	Types	Mac Mappings
		CSV		
	Address	MAC	Source Device	Source Type
	10.5.8.82	00:1D:7D:90:75:08	10.5.8.1	snmp dhcp lease
	10.5.8.82	00:1D:7D:90:75:08	10.5.8.1	snmp arp
	10.5.8.92	00:1D:92:B0:C7:56	10.5.8.1	snmp dhcp lease
	10.5.8.4	00:1F:29:26:4F:30	10.5.8.1	snmp dhcp lease
	10.5.6.233	00:1F:29:26:4F:30	10.5.8.1	snmp dhcp lease
	10.5.8.105	00:1F:5B:E7:23:F7	10.5.8.1	snmp dhcp lease
	192.168.88.254	00:1F:D0:5F:58:A1	192.168.88.1	snmp arp
	10.5.8.177	00:1F:D0:5F:58:A1	10.5.8.1	snmp dhcp lease
	192.168.88.254	00:1F:D0:5F:58:A1	192.168.88.1	ros arp
	10.5.8.3	00:21:5A:E6:E0:32	10.5.8.1	snmp dhcp lease
	10.5.8.3	00:21:5A:E6:E0:32	10.5.8.1	snmp arp
	10.5.8.3	00:21:5A:E6:E0:32	192.168.88.1	ros arp

Ruter Mikrotik

Maparea statică pe
Win2016 Server

New Reservation

?

×

Provide information for a reserved client.

Reservation name:

hr printer

IP address:

10 . 0 . 0 . 150

MAC address:

00-11-22-33-44-55

Description:

Printer for HR

Supported types

☐ Both

☒ DHCP

☐ BOOTP

Add

Close

DHCP

Configurare pe un ruter

R1(config)#service dhcp > Enables DHCP

R1(config)#ip dhcp pool mydhcp > Create a DHCP pool

R1(dhcp-config)#network 192.168.100.0 255.255.255.0 > The network used to get IP address from Router

R1(dhcp-config)#default-router 192.168.100.254 > Default gateway of Hosts

R1(dhcp-config)#dns-server 192.168.100.250 > DNS Server of Hosts

R1(dhcp-config)#exit

R1(config)#


R1(config)#ip dhcp excluded-address 192.168.100.1 192.168.100.50 > The address that we want to excluded from DHCP pool. These address never been used by Router to lease.

Configurarea DHCP pe un ruter
Cisco

Configurarea DHCP pe un ruter Tenda

FTP

Ce transferăm?



FTP

Cum transferăm



Cyberduck

FileZilla



WinSCP



SmartFTP



FREE FTP



Folosim clienți.

Vom utiliza 2 porturi

Portul 21 - control

Portul 20 - datele

Ambele țin de TCP

HTTP

Cadrul cerere

5	0.060942	192.168.0.87	148.251.41.80	HTTP	529 GET /black-cat-images.html HTTP/1.1
12	0.127709	148.251.41.80	192.168.0.87	HTTP	895 HTTP/1.1 200 OK (text/html)
14	0.412051	192.168.0.87	148.251.41.80	HTTP	472 GET /images/6TpLybM7c.jpg HTTP/1.1
15	0.415979	192.168.0.87	148.251.41.80	HTTP	474 GET /image_gallery/3256.png HTTP/1.1
37	0.479489	192.168.0.87	148.251.41.80	HTTP	472 GET /images/5iRrpzKxT.jpg HTTP/1.1
39	0.479965	192.168.0.87	148.251.41.80	HTTP	482 GET /new_gallery/bus-clipart-49.jpg HTTP/1.1
56	0.485528	192.168.0.87	148.251.41.80	HTTP	476 GET /image_gallery/389987.jpg HTTP/1.1
84	0.540391	148.251.41.80	192.168.0.87	HTTP	542 HTTP/1.1 200 OK (PNG)

> Transmission Control Protocol, Src Port: 61807, Dst Port: 80, Seq: 1, Ack: 1, Len: 475

▼ Hypertext Transfer Protocol

> GET /black-cat-images.html HTTP/1.1\r\n

Host: clipart-library.com\r\n

Connection: keep-alive\r\n

Upgrade-Insecure-Requests: 1\r\n

User-Agent: Mozilla/5.0 (Windows NT 10.0; WOW64) AppleWebKit/537.36 (KHTML, like Gecko) Chrome/86.0.4240.111 Safari/537.36\r\n

Accept: text/html,application/xhtml+xml,application/xml;q=0.9,image/avif,image/webp,image/apng,*/*;q=0.8,application/signed-exchange;v=b3;q=0.9\r\n

Accept-Encoding: gzip, deflate\r\n

Accept-Language: ro-RO,ro;q=0.9,en-US;q=0.8,en;q=0.7\r\n

\r\n

[Full request URI: <http://clipart-library.com/black-cat-images.html>]

[HTTP request 1/3]

[Response in frame: 12]

[Next request in frame: 14]

Elementul căutat

Site-ul originar al informației

Varianta minimă de browser

Tipul de informație pe care îl acceptăm

URL-ul pe care îl căutăm

Cadrul în care vine răspunsul

HTTP

Cadrul răspuns

5	0.060942	192.168.0.87	148.251.41.80	HTTP	529 GET /black-cat-images.html HTTP/1.1
12	0.127709	148.251.41.80	192.168.0.87	HTTP	895 HTTP/1.1 200 OK (text/html)
14	0.412051	192.168.0.87	148.251.41.80	HTTP	472 GET /images/6TpLybM7c.jpg HTTP/1.1
15	0.415979	192.168.0.87	148.251.41.80	HTTP	474 GET /image_gallery/3256.png HTTP/1.1
37	0.479489	192.168.0.87	148.251.41.80	HTTP	472 GET /images/5iRrpzKxT.jpg HTTP/1.1
39	0.479965	192.168.0.87	148.251.41.80	HTTP	482 GET /new_gallery/bus-clipart-49.jpg HTTP/1.1
56	0.485528	192.168.0.87	148.251.41.80	HTTP	476 GET /image_gallery/389987.jpg HTTP/1.1
84	0.540391	148.251.41.80	192.168.0.87	HTTP	542 HTTP/1.1 200 OK (PNG)

> HTTP/1.1 200 OK\r\n

Server: nginx/1.10.2\r\n

Date: Wed, 04 Nov 2020 14:55:13 GMT\r\n

Content-Type: text/html; charset=UTF-8\r\n

Transfer-Encoding: chunked\r\n

Connection: keep-alive\r\n

Vary: Accept-Encoding\r\n

Content-Encoding: gzip\r\n

\r\n

[HTTP response 1/3]

[Time since request: 0.066767000 seconds]

[\[Request in frame: 5\]](#)

[\[Next request in frame: 14\]](#)

[\[Next response in frame: 270\]](#)

[Request URI: http://clipart-library.com/images/6TpLybM7c.jpg]

Data și ora la care am primit răspunsul

Care e tipul de conținut: text, imagine, etc

Cadrul în care a fost făcută cererea

HTTP

Cum se încarcă o pagină web

<https://developers.google.com/speed/pagespeed/insights/>

<https://webpagetest.org/>

Lab Data			
■ First Contentful Paint	3.8 s	▲ Time to Interactive	12.0 s
■ Speed Index	4.8 s	■ Total Blocking Time	530 ms
▲ Largest Contentful Paint ■	13.3 s	▲ Cumulative Layout Shift ■	0.397


Opportunity	Estimated Savings
▲ Serve images in next-gen formats	8.25 s
▲ Remove unused JavaScript	2.1 s
▲ Preload key requests	2.1 s
▲ Eliminate render-blocking resources	1.14 s
■ Remove unused CSS	0.6 s

Astfel de aplicații ne pot oferi informații despre cum anume este populat un site de web și despre cum l-am face mai ușor accesibil.

HTTP

Analiză

În această imagine puteți
vedea o analiză a site-ului
cv.upt.ro





That's all for today, see you next time!